
Disinfection and Sterilization in Healthcare An Overview

**William A. Rutala, Ph.D., M.P.H.
University of North Carolina (UNC) Health
Care System and UNC at Chapel Hill, NC**

Disinfection and Sterilization Overview

- Provide overview
- Discuss processes and products
- Emerging pathogens and prions
- Special instrument reprocessing issues

Efficacy of Disinfection/Sterilization Influencing Factors

Cleaning of the object

Organic and inorganic load present

Type and level of microbial contamination

Concentration of and exposure time to disinfectant/sterilant

Nature of the object

Temperature and relative humidity






Disinfection and Sterilization

EH Spaulding believed that how an object will be disinfected depended on the object's intended use.

CRITICAL - objects which enter normally sterile tissue or the vascular system or through which blood flows should be **sterile**.

SEMICRITICAL - objects that touch mucous membranes or skin that is not intact require a disinfection process (**high-level disinfection [HLD]**) that kills all microorganisms but high numbers of bacterial spores.

NONCRITICAL - objects that touch only intact skin require **low-level disinfection**.



Processing “Critical” Patient Care Objects

Classification:	Critical objects enter normally sterile tissue or vascular system, or through which blood flows.
Object:	Sterility.
Level germicidal action:	Kill all microorganisms, including bacterial spores.
Examples:	Surgical instruments and devices; cardiac catheters; implants; etc.
Method:	Steam, gas, hydrogen peroxide plasma or chemical sterilization.

Critical Objects

- Surgical instruments
- Cardiac catheters
- Implants

Chemical Sterilization of “Critical Objects”

Glutaraldehyde ($\geq 2.0\%$)
Hydrogen peroxide-HP (7.5%)
Peracetic acid-PA (0.2%)
HP (1.0%) and PA (0.08%)
HP (7.5%) and PA (0.23%)
Glut (1.12%) and Phenol/phenate (1.93%)

Exposure time per manufacturers' recommendations



Processing “Semicritical” Patient Care Objects

Classification:	Semicritical objects come in contact with mucous membranes or skin that is not intact.
Object:	Free of all microorganisms except high numbers of bacterial spores.
Level germicidal action:	Kills all microorganisms except high numbers of bacterial spores.
Examples:	Respiratory therapy and anesthesia equipment, GI endoscopes, thermometer, etc.
Method:	High-level disinfection

Semicritical Items


- Endoscopes
- Respiratory therapy equipment
- Anesthesia equipment
- Endocavitary probes
- Tonometers
- Diaphragm fitting rings

High Level Disinfection of “Semicritical Objects”

Exposure Time \geq 12 m-30m, 20°C

Germicide	Concentration
Glutaraldehyde	\geq 2.0%
Ortho-phthalaldehyde (12 m)	0.55%
Hydrogen peroxide*	7.5%
Hydrogen peroxide and peracetic acid*	1.0%/0.08%
Hydrogen peroxide and peracetic acid*	7.5%/0.23%
Hypochlorite (free chlorine)*	650-675 ppm
Glut and phenol/phenate**	1.21%/1.93%

*May cause cosmetic and functional damage; **efficacy not verified



Processing “Noncritical” Patient Care Objects

Classification:	Noncritical objects will not come in contact with mucous membranes or skin that is not intact.
Object:	Can be expected to be contaminated with some microorganisms.
Level germicidal action:	Kill vegetative bacteria, fungi and lipid viruses.
Examples:	Bedpans; crutches; bed rails; EKG leads; bedside tables; walls, floors and furniture.
Method:	Low-level disinfection or detergent cleaning

Low-Level Disinfection for “Noncritical” Objects

Exposure time \geq 1 min

Germicide	Use Concentration
Ethyl or isopropyl alcohol	70-90%
Chlorine	100ppm (1:500 dilution)
Phenolic	UD
Iodophor	UD
Quaternary ammonium	UD

UD=Manufacturer's recommended use dilution

Disinfection and Sterilization of Emerging Pathogens

Disinfection and Sterilization of Emerging Pathogens

- Hepatitis C virus
- *Clostridium difficile*
- *Cryptosporidium*
- *Helicobacter pylori*
- *E.coli* 0157:H7
- Antibiotic-resistant microbes (MDR-TB, VRE, MRSA)
- SARS Coronavirus, avian influenza, norovirus
- Bioterrorism agents (anthrax, plague, smallpox)

Disinfection and Sterilization of Emerging Pathogens

Standard disinfection and sterilization procedures for patient care equipment are adequate to sterilize or disinfect instruments or devices contaminated with blood and other body fluids from persons infected with emerging pathogens

Creutzfeldt Jakob Disease (CJD): Disinfection and Sterilization

Decreasing Order of Resistance of Microorganisms to Disinfectants/Sterilants


Prions
Spores
Mycobacteria
Non-Enveloped Viruses
Fungi
Bacteria
Enveloped Viruses

CJD: Disinfection and Sterilization Conclusions

- Critical/SC-cleaning with special prion reprocessing
 - NaOH and steam sterilization (e.g., 1N NaOH 1h, 121°C 30 m)
 - 134°C for 18m (prevacuum)
 - 132°C for 60m (gravity)
- No low temperature sterilization technology effective*
- Noncritical-four disinfectants (e.g., chlorine, Environ LpH) effective (4 log decrease in LD₅₀ within 1h)

*VHP reduced infectivity by 4.5 logs (Lancet 2004;364:521)

Endoscopes/AERS



ENDOSCOPE DISINFECTION

- CLEAN-mechanically cleaned with water and enzymatic/detergent cleaner
- HLD/STERILIZE-immerse scope and perfuse HLD/sterilant through all channels for at least 12 min
- RINSE-scope and channels rinsed with sterile water, filtered water, or tap water followed by alcohol
- DRY-use forced air to dry insertion tube and channels
- STORE-prevent recontamination

Endoscope Safety

- Ensure policies equivalent to guidelines from professional organizations (APIC, SGNA, ASGE);
policies = practices
- Are the staff who reprocess the endoscope specifically trained in that job?
- Are the staff competency tested at least annually?
- Conduct IC rounds to ensure compliance with policy



Special Instrument Reprocessing Issues



Endocavitary Probes

- Probes-Transesophageal echocardiography probes, vaginal/rectal probes used in sonographic scanning
- Probes with contact with mucous membranes are semicritical
- Guideline recommends that a new condom/probe cover should be used to cover the probe for each patient and since covers may fail (1-80%), HLD (semicritical probes) should be performed

Endocavitary Probe Covers

- Sterile transvaginal probe covers had a very high rate of perforations before use (0%, 25%, 65% perforations from three suppliers)
- A very high rate of perforations in used endovaginal probe covers was found after oocyte retrieval use (75% and 81% from two suppliers) but other investigators found a lower rate of perforations after use of condoms (0.9-2.0%)
- Condoms superior to probe covers for ultrasound probe (1.7% condom, 8.3% leakage for probe covers)

Conclusions

- When properly used, disinfection and sterilization can ensure the safe use of invasive and non-invasive medical devices.
- Method of disinfection and sterilization depends on the intended use of the medical device
- Cleaning should always precede high-level disinfection and sterilization
- Current disinfection and sterilization guidelines must be strictly followed.

Disinfection and Sterilization Overview

- Provide overview
- Discuss processes and products
- Emerging pathogens and prions
- Special instrument reprocessing issues

disinfectionandsterilization.org

Thank you

References

- Rutala WA, Weber DJ. CJD: Recommendations for disinfection and sterilization. *Clin Inf Dis* 2001;32:1348
- Rutala WA, Weber DJ. Disinfection and sterilization: What clinicians need to know. *Clin Infect Dis* 2004;39:702
- Rutala WA, Weber DJ, HICPAC. CDC guideline for disinfection and sterilization in healthcare facilities. In press.
- Rutala WA. APIC guideline for selection and use of disinfectants. *Am J Infect Control* 1996;24:313